

DA1432 Anleitung Gerätesoftware (Firmware) Update

1. DA1432 Firmware Paket „fw_DA1432_app_XXX.zip“ (XXX: Versionsnummer) von der Webseite auf Ihren PC laden und entpacken
2. Gerät mit PC über mitgeliefertes USB Kabel verbinden und PC APP starten
3. Tab "System" und darunter "Update, Reset" auswählen
4. Unter "Update" in das Eingabefeld hinter "Neue Firmware" mit Mauszeiger klicken und die Firmware „fw_DA1432_app_XXX.bin“ (XXX: Versionsnummer) Datei auswählen
5. Nachdem die Firmware Datei ausgewählt wurde, den "Start update" Knopf drücken

Hinweis: USB Verbindung während des Update Prozesses nicht unterbrechen!

6. Beim Verlassen der PC APP werden Sie eventuell noch einmal bei einigen Tabs zum Übernehmen der Daten aufgefordert. Bitte bestätigen, wenn die Daten erhalten bleiben sollen.

DA1432 instructions FW Update

1. Download the DA1432 firmware „fw_DA1432_ XXX.bin“ (XXX: version number) from the website to your PC and unzip
2. Connect the device to your PC with the supplied USB cable and start the PC APP
3. Select tab "System" and there "Update, Reset"
4. Under "Update", click in the input field behind "New Firmware" and select the firmware file "fw_DA1432_XXX.bin" (XXX: version number)
5. After the firmware file has been selected, press the "Start update" button

Note: Do not interrupt the USB connection during the update process!

6. When leaving the PC APP, maybe on some tabs you will be prompted again to take over the data. Please confirm if this data should be retained.